

STRYKER SLAT TREADMILL

TRUE heritage and engineering come together to provide your facility with the TRUE Stryker Slat Treadmill. The Stryker features a running surface of vulcanized rubber slats that are more durable and require less maintenance than the conventional conveyor belt system of traditional treadmills. The individual shock-absorbing slats provide a running surface closer to the natural feel of outdoor running for those looking for a more realistic training experience.

FEATURES

- Less downtime and overall lower cost-of-ownership than traditional treadmill
- Requires less maintenance; no need for tracking adjustments, waxing, or flipping of deck with slat system
- Ergonomic pistol-grip handles with thumb controls and center pod with quick speed and incline keys
- Over-molded rubber slat belt with 62 individual slats and running surface of 22"/55 cm x 60"/152 cm
- Three emergency stops for safety (on console, center pod, and safety key)

SPECIFICATIONS

DIMENSIONS (L X W X H)

72" L x 35" W x 64" H / 182 cm x 89 cm x 163 cm

SPEED

1 to 12.0 MPH / 1.6 to 19.3 KPH (0.5 increments)

INCLINE/DECLINE LEVELS

0% to 25% (-3% to 22% with Decline Kit)

PRODUCT WEIGHT

599 lbs / 271.7 kg

COLOR

Charcoal/Black



CONSOLE OPTIONS



ENVISION II
22" Touchscreen



ENVISION II
16" Touchscreen



ENVISION II
9" Touchscreen



SHOWRUNNER II
16" Integrated LCD



EMERGE II
LED Console



IGNITE II
LED Console

STRYKER SLAT TREADMILL

TECHNICAL SPECIFICATIONS	Power Source	120V/16A Dedicated (NEMA 5-20 Receptacle) 220-240V/8A Option Available	
	Cord Length	12' / 3.7 M	
	Power Factor Correction (PFC)	Standard	
	Incline Motor	1,200 lbs. of thrust	
	Speed Sensor	Optical	
	Slat	62 vulcanized rubber slats - durometer of 75 shore	
	End Rollers	58 mm diameter with shielded bearings	
	Slatbelt Support Bearings	22 mm diameter with sealed bearings	
	Frame Construction	Robotically Welded Heavy-Gauge Steel	
	Speed Range	1 to 12.0 MPH / 1.6 to 19.3 KPH	
	Incline/Decline Range	0% to 25% (-3% to 22% with Decline)	
	Quick Access Control	Mechanical thumb switches and center pod with quick keys (speed and incline) as well as emergency stop	
	Handrail Design	Extended Handrails with Molded Rubber, Moisture-Resistant Grips	
	Contact Heart Rate Monitoring	Yes	
	Wireless Heart Rate Monitoring	Polar® Compatible	
	AVAILABLE CONSOLES	Envision II 22", Envision II 16", Envision II 9", ShowRunner II, Emerge II, Ignite II	
	ASSET TRACKING	EcoFit Compatible	
SAFETY	Safety Clip	Standard/Removable	
	Extended Handrails	Standard	
	Large Straddle Covers	Standard	
	User Detection	User Present Detection™	
REGULATORY APPROVALS	ETL UL1647, CSA, CE, EN957, (ISO 20957), FCC		
EXTRAS	Special Features	Reading Rack, Two (2) 5" / 12.7 cm square water bottle holders, Accessory Tray (5" / 12.7 cm x 9" / 22.86 cm Textured Plastic)	
PHYSICAL SPECIFICATIONS	Footprint	72" L x 35" W x 64" H / 182 cm x 89 cm x 163 cm	
	Running Surface	22"/55 cm x 60"/152 cm	
	Machine Weight	599 lbs / 271.7 kg	
	Shipping Weight	649 lbs / 294.3 kg	
	Maximum User Weight	500 lbs / 226.7 kg	
	Deck Step-Up Height	13" / 33.02 cm	
	Portability	Rear Retractable	
WARRANTY	Warranty Type	Commercial (all dues paying facilities, regardless of usage)	
	Frame	7 Years	
	Motor	5 Years	
	Parts	3 Years	
	Labor	3 Years	
	Console	3 Years	

Warranties outside the U.S. and Canada may vary - Please contact your dealer for details. Specifications subject to change without notice.



truefitness.com | 800.426.6570 | 636.272.7100

©2021 TRUE Fitness Technology, Inc