

Designed on the solid CU800 platform, the CU800ENT incorporates touchscreen technology on a large 10.1" ENTERTAINMENT display. TV, web browsing, and music streaming are all made possible within a user interface that is easy to use and adaptable to nearly any facility. From the 40 levels of resistance and numerous program options to the extra-smooth ride and heavy-duty feel, the CU800ENT has everything your clients could want in an upright bike.

FEATURES

- Large 10.1" touchscreen with TV, web browsing, and music streaming
- 3 different workout display modes give users a variety of workout feedback
- Contact & Telemetric heart rate capabilities to make the workout more effective
- Oversized foot pedals with fast latching system
- Dual spring seat with fore/aft adjustment for extra comfort and a custom fit
- 40 levels of resistance to satisfy the needs of beginners or advanced exercisers

CONSOLE FEATURES

The CU800ENT features a modern 10.1" touchscreen display and electronics package that allows your clients to watch TV, browse the web, and stream their favorite music. Preset programs include a wide variety of popular workouts for the average user while a Gerkin Protocol Fitness Test, heart rate programs and a custom program are available for more serious users. Ergonomically friendly pulse grip handles are mounted comfortably within reach for a more natural hand position while a Turbo cooling fan keeps your clients cool to encourage them to workout longer.



3.5mm Headphone Jack









TV

Watch your favorite TV shows right on the console, control the volume, and switch channels by tapping the virtual buttons on the screen

DISPLAY

The system provides 3 different viewing modes (Simple, Track, Dashboard) to fine tune your workout experience

INTERNET

Easily access preselected websites and online apps such as YouTube, Facebook, and Twitter through the internet on the touchscreen

SETTINGS


The console is fully configurable with in-depth console settings. Easily set up the internet connections and modify what websites are available for the user. Also, customize the TV settings, perform diagnostics and maintenance, change default language, update software version, and more

EQUIPMENT SPECIFICATIONS

| Console | 10.1" Touchscreen Display, TV Tuner w/Coaxial or HDMI Input, Wi-Fi 802.11 b/g/n or Ethernet, 3.5mm Headphone Jack, Bluetooth 4.0, USB Service Port |
|-----------------|---|
| Programs | Manual, Hill, Fat Burn, Cardio, Strength, Interval, Fit Test, HR, Constant Power, Custom |
| Heart Rate | Contact & Telemetric (Chest strap sold separately) |
| Resistance | 40 levels |
| Drive Train | Poly-V Belt w/ Self-Tensioner |
| Power | 120 Volts; 15 Amp Circuit recommended |
| Flywheel System | 30 lbs. |
| Pedals | Oversized w/ Fast Latching System |
| Frame | Heavy-Gauge High-Strength Steel w/ Durable Powder-Coat Paint |
| Dimensions | 42" x 21" x 53" |
| Product Weight | 115 lbs. |
| Max User Weight | 450 lbs. |

WARRANTY INFORMATION Commercial Warranty (Non-Dues Paying Facilities) Lifetime: Frame | 5 Years: Parts & Electronics | 2 Years: Labor

Console - 3 Years: Parts | 1 Year: Labor



SALES@SPIRITFITNESS.COM

WWW.SPIRITFITNESS.COM