



Robotically welded heavy-gauge frame with durable steel side rails

Spacious 22" x 62" running surface

Maintenance free deck system

3.5 HP AC motor

TR7000i - COMMERCIAL TREADMILL



Made for iPad

CONSOLE FEATURES

Display	Large 6.5" backlit LCD screen with scrolling alphanumeric messaging, program profile showing workout progress, and simultaneous display of all readouts Three additional LED displays with readouts for time, speed, and incline
Readouts	Program name, date and time, speed, incline, distance, calories, steps, heart rate and pace
Programs	Two heart rate control programs, and 17 programs grouped by exercise motivation for weight loss, healthy living, and sports training
Quickstart	Yes
USB Ports	2 USB ports to automatically save your exercise data and charge your wireless mobile device simultaneously
Bluetooth	Wirelessly connect to your supported iOS tablet for additional console functionality and control including graphical heart rate tracking, elevation change, and average heart rate
Heart Rate	Grip pulse and heart rate telemetry
Media Holder	Book, magazine, and tablet computer holder
Intelli-Key™	Button lighting system prompts users through program set-up and operations
Emergency Stop	Magnetic safety clip, when disengaged, immediately turns off power, bringing the treadmill to a gentle stop
Units of Measure	Standard and metric settings
Language Support	English

MECHANICAL FEATURES

Speed	0.5 - 12.0 MPH / 0.8 - 19.3 KPH
Incline	0 - 15%
Running Surface	22" W x 62" L / 56cm W x 157.5cm L
Belt	Low maintenance, multi-ply polyester belt with a PVC non-slip surface
Drive Motor	3.5 HP continuous duty AC
Incline Motor	1,000 lbs. maximum lift
Rollers	3" crown rollers keep belt centered
Deck Suspension	Independent shock absorbers
Deck	1" melamine laminated reversible deck medium-density fiber board
Power Requirement	110 - 120 VAC / 220 - 240 VAC (depending on country standard)
Dimensions	80.5" L x 33.25" W x 61" H / 204.5cm L x 84.4cm W x 154.9cm H
Net Weight	368 lbs. /167 kg
Gross Weight	390 lbs. /176.9 kg
Max. User Weight	400 lbs. /181 kg
Medical Handlebars	Optional